



CLEAR
OFF



TIMER



FUNC



CLEAR
OFF



power on | start laser | measure distance

cancel current operation, switch laser off

change distance reference

start timer (automatic measurement)

show memory entries

show extended measurement information

show device information

change distance unit

switch to permanent front reference

power off

angle unit: degrees | grad



FUNC

CLEAR
OFF

CLEAR
OFF

CLEAR
OFF

CLEAR
OFF



FUNC

silent mode on/off



backsight mode on/off



beep on/off



display illumination on/off



back reference: case/endpiece



CLEAR
OFF

calibration mode on/off

CLEAR
OFF

clear unsent memory

CLEAR
OFF

Bluetooth on/off

CLEAR
OFF

locked power off



triple shot check on/off



DistoX2

c h e a t
s h e e t

(lower left corner)