



CLEAR
OFF



TIMER



FUNC



CLEAR
OFF



power on | start laser | measure distance

cancel current operation, switch laser off

change distance reference

start timer (automatic measurement)

show memory entries

show extended measurement information

show device information

change distance unit

switch to permanent front reference

power off

angle unit: degrees | grad



FUNC

CLEAR
OFF

CLEAR
OFF

CLEAR
OFF

CLEAR
OFF



FUNC

silent mode on/off

backsight mode on/off



beep on/off

display illumination on/off



back reference: case/endpiece



calibration mode on/off

clear unsent memory



DistoX2

**cheat
sheet**

Bluetooth on/off

locked power off

triple shot check on/off

▼ (lower left corner)

