



CLEAR OFF



TIMER



FUNC



CLEAR OFF



power on | start laser | measure distance



FUNC

silent mode on/off



—

backsight mode on/off



cancel current operation, switch laser off



—

beep on/off



+

display illumination on/off



FUNC

back reference: case/endpiece



change distance reference

CLEAR
OFF

calibration mode on/off

start timer (automatic measurement)

CLEAR
OFF

clear unsent memory

show memory entries

CLEAR
OFF

FUNC

Bluetooth on/off



show extended measurement information

CLEAR
OFF

locked power off

DistoX2

c h e a t
s h e e t

show device information

change distance unit

switch to permanent front reference

power off

angle unit: degrees | grad



—

triple shot check on/off

▼ (lower left corner)